



BE SAFE! DON'T OVERLOAD YOUR CLAMP HOUSING!
BE AWARE OF HEAT AND PRESSURE BUILD UP

- 1. CONTINUOUS DRIVING CAUSES HEAT BUILD UP
- 2. HEAT CAN CAUSE EXCESS CLAMP PRESSURE
- 3. EXCESS CLAMP PRESSURE CAN DAMAGE CASTING

SOLUTION: RELAX & RE-SET JAWS PERIODICALLY THROUGHOUT THE DAY TO RELIEVE EXCESS PRESSURE

HEAT PRESSURE EXPLAINED